


DR-MT Installation Instructions 6-20 v.3

Tools needed: 2) 7/16" Either sockets or open end wrenches, and 2) 9/16" Either sockets or open end wrenches



MAIN COMPONENTS

- A Receiver Base
- B Adjustable Upright
- W/ Swivel Tab
- C 3) pc Support Arm
- 1) 12" center 2) 16" ends
- D 4) Mountain Hooks
- E 2) Retainer Brackets

One set per can come std with order, additional sets can be ordered.


FASTENERS

- 12) 1/4" x 3/4" bolts, nuts and lock washers
- 1) 3/8" x 1" bolt, washer and , lock nut
- 2) 2" PTO clips

Installation Videos

garbagecommander.com
or
youtube.com

Step 1- Bolt the Adjustable Upright (B) to the receiver base (A)




UNDER SIDE VIEW OF BASE AND UPRIGHT

The receiver base (A) bends will go down, and slip into the adjustable upright (B).

Step 2- Bolt the three overlapping arms (C) with 4) 1/4" x 3/4" bolts, lock washers and nuts .


** Arms can be set for two lengths - either 36" (A) or 40" long (B) **

40" arm use this hole pattern



B

36 " arm use this hole pattern



16" Top Arm

12" Center Arm goes under the
16" longer arms

Hooks can mount to any hole, but arms must have two bolt each side

The support arm's angle will bend downward and toward the front. The outer 16" support arms will overlap the top of the 12" center arm. Screws that are used for the support arm, can also have the Mountain Hook assembled to them, if the hole patterns workout using that space. We have shipped 12 sets of nuts and bolts but you might only need 10 sets.

NOTE: If 16" support arms are installed under the bottom of the 12" arm, holes will not line up.

Tip: Before final assembly of the arm (in step two), take the arm with only two screws attached and lay it on top of your trash cans near the handles. First place the cans side by side with about 1" of space between them. Now it will be easier to select the best hole pattern to use for mounting the hooks. You might need to reset the arm size to get the best hook placement. Now go to step three and finish adding the hooks to the arm. Make sure arms have two bolts on each side securing the arms together.

Note: the **arm length will not** be the same length as the overall trash cans.



Step 3- Mount the 4) MT- Hooks and 2) Retainer bracket to the support arm

You can use the inner bolt hole that are also for fastening the two arms together along with any of the other holes at each end of the support arm. The outer holes are spaced at 1-1/2" increments to fit most of todays wheeled totes
Install the MT- Hooks using the 1/4" x 3/4" bolt, lock washers and nuts.

* MT- hooks mount to the face of the support arm, the lower tab will wrap under the bottom edge of the support arm



* We suggest to add on the two inner hooks the Retainer brackets. They slip behind and under the support arm.

The retainer brackets can be installed in any spot as long as there is one per can.

Note: Push the retainer bracket tight to the under side so it will stay straight and inline with the hook.

* Tighten the bolts so hooks will not move.

Backside view




When transporting your wheeled totes with steep or challenging grades, we recommend securing the handle using the PTO spring clip one per can comes standard with order.

Spring clip can be bent outward to make fastening easier.

If you want to have two retainer brackets and PTO clips per can, they can be ordered from our website.

We also offer on our website Ball hold down straps that are easy to apply and give extra holding if PTO clips are hard to use.

Step 4- Take the assembled upright and receiver base, and attach the support arm



Use the 3/8 x 3/4" bolt, washer and black lock nut to secure support arm to the swivel tab on top of the adjustable upright (B).

Face of support arm: The assembled support arm should be installed with the angle bends facing backward and the support arm tab forward.

Make sure the 3/8" washer is between the swivel base and the support arm as a spacer.

TIGHTEN SNUG, so the arm is not loose and moves harder, but can still pivot.

Allowing the support arm to swivel on the base but not wobble.

Warnings:

- Keep all nuts tightened
- Do Not exceed 15 MPH, or 150 lbs.
- Do Not carry passengers
- Do Not use on public roads

Turn off vehicle and put in park before attaching your Garbage Hook.

****Garbage Hooks are designed for towing,**

DO NOT backup with cans attached. Damage may accrue**

Thank you for your order, as a small company we truly appreciate your business!

*If you have any questions or concerns with your order, text us at 608- 728-2709
or send an email to - info.garbagecommander@gmail.com*

Before leaving a negative review, contact us, we promise to make things right with you.

Help us grow by spreading the word and taking the time to leave a positive review.



Garbage Commander by:

LaMalco LLC – PO Box 2812 Janesville, WI. 53547-2812

Garbage Hooks are patented and made in the USA.

Patent US 9,789,741 B1

